



## High Power RF Driver: For Acousto-optic Q-Switch

## MQH0XX-YYDM-ZZZ

Former Model Number: 390XX-YYDMZZZ-A

## **Description:**

The MQH0XX-YYDM-ZZZ module is a High Power RF Driver, designed to drive a Q-Switch. The driver has two digital modulation inputs: Fixed and Variable. These controls allow the customer to issue a pulse command of a "Fixed" pulse width, the duration determined by the Driver's pulse width control, settable by the customer, or issue a "Variable" pulse command, the duration determined by the input signal's pulse width. The output power is controlled by the analog input, where the mode of operation is defined by ZZZ = A05 normal analog mode, or R05 analog switched to full RF mode or a triggered RF Ramp Down mode where ZZZ = FPS first pulse suppression mode or PPK pre-pulse kill mode. The choices of Frequency (XX), Output Power (YY), and Power Control (ZZZ) option are "Factory Set" when ordered. The RF Driver requires forced air cooling.

The product delivered will be manufactured to be compliant with EU Directive 2011/65/EU for Reduction of Hazardous Substance. The product will be manufactured to other standards upon customer request.

## **Key Features**:

- 24, 27.12, 40.68, 68, or 80 MHz RF Frequency (XX)
- 0.01% Quartz Stabilized
- Up to 100\* watts RF power output (YY)
- Two TTL Digital Modulation Inputs: fixed and variable pulse width.
- Analogue Modulation or Triggered RF Ramp Down Mode (ZZZ)
- Up to 100 kHz Pulse Rate.
- Fault Protection on Low Power, High Power, and High VSWR
- Operates on 28 VDC

### Applications:

- RF Driver for an Acousto-Optic Q-Switch Device used to spoil the "Q" of a CW laser so as to output an intense pulse of light.
- Used in industrial, medical, or military applications.

IWDS038 V1.0 Page 1 of 11



#### MQH0XX-YYDM-ZZZ

### **SPECIFICATIONS:**

PARAMETER SPECIFICATION

Output Frequency is "Factory Set When Ordered": XX = 24, 27, 41, 68, or 80

RF Frequency: 24.00, 27.12, 40.68, 68.00, 80.00 MHz ± 0.01%

Spurious Levels: -50 dBc maximum
Harmonic Distortion -30 dBc maximum

Digital Inputs:

Fixed Mod In TTL Levels, Triggered on Rising Edge. Pulse Width Applied >50 ns.

Variable Mod In TTL Levels, TTL High = RF off

Extinction Ratio: 35 dB minimum
RF Rise Time 10% to 90% 500 ns maximum
RF Fall Time: 90% to 10% 100 ns maximum

Modulation Repetition Rates: 1 Hz to 100 kHz for Fixed Modulation

DC to 100 kHz for Variable Modulation

Fixed Modulation Output Pulse Width Adjustment Range: 1 to 14 μs, Customer Adjustable

Available Pulse Control Options: **ZZZ** = Mode

Pulse Control Mode is <u>"Factory Set When Ordered"</u>: FPS = First Pulse Suppression See Figure 2

PPK = Pre Pulse Kill

A05 = Analog Control

R05 = RF Switched to Analog Control

Digital Modulation Only

See Figure 3

See Figure 4

See Figure 5

See Figure 5

FPS Trigger / Analog input Units configured with FPS, PPK: TTL Levels,

Triggered on TTL Rising Edge.

Units configured with A05, R05: 0 to 5 volts analog.

\*RF Output Power "Factory Set When Ordered": YY = 50 or 100 watts nominal for 24, 27, 41, and 68 MHz units

Adjustable from 25 to 100 watts.

50 watts nominal for 80 MHz units, Adjustable from 20 to 50 watts.

Output Impedance: 50 ohms nominal

Shutter Output: 0.3 sec delay. Opens on fault. Capable of

sinking 1 amp at 28 volts Maximum.

Supply Voltage Input  $+28 \text{ VDC} \pm 1\%$ 

Supply Current Input 6.5 A for 50 W units 9.0 A for 100 W units

Operating Temperature +10°C to +55°C

Air Flow through Heat Sink > 36 CFM (> 17 litres / second) @ 25°C

**MAXIMUM RATINGS:** 

Supply Voltage: 30 volts DC maximum

Power Output: No DC Feedback Allowed

Storage Temperature: -20°C to +85°C



**CONNECTORS & MECHANICAL:** Located on front panel

RF Output Connector: **BNC Female** 

**Power Supply Connections:** Vcc Solder Post

Return Ground Lug

**25PIN D-SUB CONNECTOR PINOUT:** Located on front panel. See Detail A of Outline Drawing. 1

+5V output for external fault indicators, 75 mA available. +5V

2 - 3NC No connection.

4 THERM RTN Ground – to be used as a return for THERM.

NC 5 No connection.

Thermostat connection – driver enters a fault condition unless this is 6 **THERM** 

Shorted to ground.

7 DRV TEMP Normally HIGH, goes LOW when the driver is in an overheat fault.

8 **QS TEMP** Normally HIGH, goes LOW when no short present on THERM.

9 **HVSWR** High VSWR fault, normally HIGH, goes LOW during fault.

10 LP Low RF Power indicator, normally HIGH, goes LOW while driver

output is below the Low RF Power threshold.

HP 11 High RF Power fault, normally HIGH, goes LOW during fault.

MOD IN ANALOG Controls the output power level in A05 and R05 models 12

Pulse LOW to reset the driver from a fault condition. This line should 13 **FAULT RESET** 

not be held LOW or it will defeat some of the fault conditions.

**FPS TRG** 14 Triggers a suppression pulse on a RISING edge.

15 MOD IN FIXED Turns the driver off for the duration set by the pulse width control.

MOD IN VARIABLE 16 Turns the driver off while this input is HIGH.

SYNC OUT 17 Outputs a signal synchronized to the modulation output.

18-19 NC No connection.

20 SHUTTER 0.3 sec delay. Opens on fault. Capable of sinking 1 amps at 28 volts

maximum.

21 -24 NC No Connection

25 **GND** Ground.

Note: Some Control Signals Shown on Outline Drawing are Not Available on Standard Units.

#### **INDICATORS:** Located on front panel

Power Power Indicator – The module has 28V applied on the DC connector.

Low Power Faults after 0.3 second, power below LP Set Point.

Resets on power adjusted above Set Point.

High Power Faults when power above HP Set Point.

Reset required after removing fault.

High VSWR Faults when reflected power above VSWR Set Point.

Reset required after removing fault.

QS Temp Faults on open Thermostat.

Resets on closed Thermostat. (Q-Switch below set temperature)

**DRV Temp Driver** The internal temperature of the module has reached 60°C.

The driver will remain in this fault condition until it cools down.

Page 3 of 11



#### ADJUSTMENTS: Located Inside Unit Through Holes in Module Top Cover

RF Power Level Adjustment Adjusts the output RF Power.

LP Set Point Adjusts the minimum power threshold. If the module's output goes

Below this set value, the low power warning light will turn on, but the driver will continue to output power. This is a warning, not a true fault condition.

HP Set Point Adjusts the maximum power threshold for the module. If the output rises

above this threshold, the module will cease output until it is reset.

VSWR Set Point Adjusts the module's tolerance for a mismatched load connected to RF Out.

If a mismatch is detected, the driver will cease outputting power until reset.

Pulse Width Adjusts the length of time the driver outputs no RF energy after receiving a

trigger. 1µs to 14µs.

The following adjustment is not used on units configured with FPS or PPK:

Threshold Sets the point below which the analog voltage is ignored and the system

output is shut off.

The following adjustments are not used on units configured with Analog Input (A05, R05):

FPS Start Adjusts the initial power level of the first pulse.

FPS Slope Adjusts how quickly the RF pulses return to their normal level after the FPS

has been triggered. 20  $\mu s$  to 300  $\mu s$ .


FPS Window Adjusts the duration of the suppression pulse cycle. 20  $\mu$ s to 300  $\mu$ s.

Note: Some Adjustments Shown on Outline Drawing are Not Available on Standard Units.



#### **Mechanical Dimensions:**

#### Dimensions in inches and [mm]



Page 5 of 11



### **Control Diagrams**

Figure 2

## MQH0XX-YYDM-FPS (HIGH POWER) First Pulse Suppression Control Connection and Control Diagrams






Figure 3

MQH0XX-YYDM-PPK (HIGH POWER) Pre-Pulse Kill Control
Connection and Control diagram






Figure 4

# MQH0XX-YYDM-A05 (HIGH POWER) Analog 5 Volt Control Connection and Control Diagrams






Figure 5

# MQH0XX-YYDM-R05 (HIGH POWER) RF Switch to Analog 5 Volt Control Connection and Control Diagrams







Figure 6

## MQH0XX-YYDM (HIGH POWER) Digital Control Only Connection and Control Diagrams






#### **Ordering Codes:**

**Example: MQH027-100DM-A05** 

A 27 MHz RF Driver with two TTL Digital Modulation inputs (fixed and variable pulse width) and an analog input (A05) which enables control of the RF output power. Designed to Drive an AO Q-Switch requiring 100 watts RF Power or less. Delivered as a RoHS compliant, forced air cooled OEM Module.



#### **Technical Assistance & Customization**

Our Engineering and Sales team are available to discuss your requirements and will assist you in selecting the most appropriate acousto-optic Q-Switch/ Driver combination for your application.